



SANTERNO Inverter 編碼原則

TL = Transformer Less 無變壓器

TE = Transformer External 變壓器外接

NA = North America 北美用

Basically, TE and TL have the same meaning, we use TL mainly for the United States

Therefore: TG610 1000V TL NA - 340 = TG610 1000 Volt, Transformer less, North America - 340

等於TG610 1000V TL NA - 340 = TG610 1000 V, 無變壓器, 北美用- 340伏

CM = compact model 緊湊型

OD = out door 屋外型

ST= standard 標準型