


# Fire emergency switches



**Motor driven  
DC disconnect switch**



**Fire alarm button**  
(digital signal, pulse, NO or NC)



**Emergency stop push-button**  
(digital signal, pulse, NO or NC)