


Fire emergency switches



**Motor driven
DC disconnect switch**



Fire alarm button
(digital signal, pulse, NO or NC)



Emergency stop push-button
(digital signal, pulse, NO or NC)