


POSITION OF HANDLE

|   |     |
|---|-----|
| 1 |     |
|   | OFF |
|   |     |
|   |     |
|   |     |
| 2 |     |
|   | 1-A |
|   | 2-B |
|   | 3-C |
|   | 4-D |
|   | 5-E |
|   | 6-F |
| 3 |     |
|   | OFF |
|   |     |
|   |     |
|   |     |
| 4 |     |
|   | 1-A |
|   | 2-B |
|   | 3-C |
|   | 4-D |
|   | 5-E |
|   | 6-F |

| Ith | Ie  | Ue         |
|-----|-----|------------|
| 25A |     |            |
|     | 25A | 1000V DC21 |



|      |  |        |      |         |
|------|--|--------|------|---------|
| B    |  |        |      |         |
| A    |  |        |      |         |
| Rev. |  | Drn by | Date | App. by |

SANTON TYPENR. RP 1H625/50A0512

|                                                                                                  |                                                                                                                                                                                    |                                |
|--------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------|
| Drn by : C.Z.-                                                                                   | Date : 18-07-2006                                                                                                                                                                  | App. by :                      |
|  <b>santon</b> | Santon International bv<br>Hekendorpstraat 69<br>3079 DX Rotterdam<br>Holland<br>Tel. +31 (0)10 283 26 00<br>Fax +31 (0)10 429 45 46<br>info@santon.nl<br>www.santonswitchgear.com | Computer nr.<br><b>50A0512</b> |