


# Energy Management Energy Meter Type EM21 72D



- Multi-use housing: for both DIN-rail and panel mounting applications
- MID "annex MI-003" (Measuring Instruments Directive) compliant

- Class B (kWh) according to EN50470-3
- Class 1 (kWh) according to EN62053-21
- Class 2 (kvarh) according to EN62053-23
- Accuracy ±0.5 RDG (current/voltage)
- Energy meter
- Instantaneous variables readout: 3 DGT
- Energies readout: 6+1 DGT
- System variables: W, var, PF, Hz, Phase-sequence.
- Single phase variables: V<sub>LL</sub>, V<sub>LN</sub>, A, PF
- Energy measurements: total kWh and kvarh
- TRMS measurements of distorted sine waves (voltages/currents)
- Self power supply
- Dimensions: 4-DIN modules and 72x72mm
- Protection degree (front): IP50
- Application adaptable display and programming procedure (Easyprog function)
- Easy connections management
- Detachable display

#### **Product Description**

Three-phase energy meter with removable front LCD display unit. The same unit can be used either as a DIN-rail mounting or a panel mounting energy meter. This general purpose threephase energy meter is suitable for both active and reactive energy metering for cost allocation but also for main electrical parameand ter measurement retransmission (transducer function). Housing for DINrail mounting with IP50

(front) protection degree. Current measurements carried out by means of external current transformers and voltage measurements carried out either by means of direct connection or by means of potential transformers. EM21-72D is provided, as standard, with a pulsating output for active energy retransmission. In addition a 2-wire RS485 communication port is available as an option.

How to order	EM21 72D AV5 3 X O X X
Model-	<u>-</u>
Range code ———	
System-	
Power supply ——	
Output 1	
Output 2	
Option———	

#### Type Selection

Range codes	Range codes System Po		Output 1
AV5 (*): 400V <sub>LL</sub> AC, 5(6)A or 1(6)A (***) (CT connection) AV6 (**): 120V <sub>LN</sub> /230V <sub>LL</sub> AC 5(6)A or 1(6)A (***) (VT/PT and CT connections)	3 (*): balanced and unbalanced load: 3-phase, 4-wire; 3-phase, 3-wire; 2-phase, 3-wire; 1-phase, 2-wire	X (*): Self power supply from 18V to 260VAC VLN, 45 to 65 Hz	O (*): Single static output (opto-mosfet)
Output 2	Options	_	
X (*): None S (**): RS485 port	X (*): None	_	(*) as standard. (**) on request. (***) the range is available but not in compliance with the MID.



# Input specifications

Rated inputs	System type: 3	Energies	Imported Total: 6+1DGT or
Current type	Not isolated (shunt inputs). Note: the external current		7DGT
	transformers can be con-	Overload status	EEE indication when the
	nected to earth individually.		value being measured is exceeding the "Continuous
Current range (by CT)	AV5 and AV6: 5(6)A. The		inputs overload" (maximum
3 ( , , , ,	"1(6)A" range is available		measurement capacity)
	but not in compliance with	Max. and Min. indication	Max. instantaneous vari-
	the MID.		ables: 999; energies:
Voltage (direct or by VT/PT)	AV5: 400VLL;		999 999.9 or 9 999 999.
	AV6: 120/230VLL		Min. instantaneous vari-
Accuracy (Display + RS485)	In: see below, Un: see below		ables: 0; energies 0.0.
(@25°C ±5°C, R.H. ≤60%, 48 to 62 Hz)		LEDs	Red LED (Energy con-
AV5 model	In: 5A, Imax: 6A; Un: 160 to		sumption)
7 WO THOUGH	260VLN (277 to 450VLL).		0.001 kWh by pulse if CT ratio x VT ratio is <7;
AV6 model	In: 5A, Imax: 6A; Un: 40 to		0.01 kWh by pulse if CT
	144VLN (70 to 250VLL).		ratio x VT ratio is ≥ 7.0
Current AV5, AV6 models	From 0.002ln to 0.2ln:		< 70.0;
	±(0.5% RDG +3DGT).		0.1 kWh by pulse if CT
	From 0.2In to Imax:		ratio x VT ratio is ≥ 70.0
Dhaga noutral voltage	±(0.5% RDG +1DGT).		< 700.0;
Phase-neutral voltage	In the range Un: ±(0,5% RDG +1DGT).		1 kWh by pulse if CT ratio
Phase-phase voltage	In the range Un: ±(1% RDG	Max frequency	x VT ratio is ≥ 700.0; 16Hz, according to
. Hass phass remage	+1DGT).	Max frequency	EN50470-3
Frequency	Range: 45 to 65Hz;		Green LED (on the terminal
	resolution: ±1Hz		blocks side) for power on
Active power	±(1%RDG +2DGT).		(steady) and communica-
Power Factor	±[0.001+1%(1.000 - "PF		tion status: RX-TX (in case
Popotivo power	RDG")]. ±(2%RDG +2DGT).		of RS485 option only)
Reactive power Active energy	class B according to		blinking.
, teave energy	EN50470-1-3;	Measurements	See "List of the variables
	class 1 according to	Mathad	that can be connected to:"
	EN62053-21.	Method	TRMS measurements of distorted wave forms.
Reactive energy	class 2 according to	Coupling type	By means of external CT's.
	EN62053-23.	Crest factor	In 5A: ≤3 (15A max. peak).
	In: 5A, Imax: 6A; 0.1 In: 0.5A.	Current Overloads	iii o, ii <u>se (re, tilia, ii peary.</u>
	Start up current: 10mA.	Continuous	6A, @ 50Hz.
Energy additional errors		For 500ms	120A, @ 50Hz.
Influence quantities	According to EN62053-21,	Voltage Overloads	
•	EN50470-1-3, EN62053-23	Continuous	1.2 Un
Temperature drift	≤200ppm/°C.	For 500ms	2 Un
Sampling rate	1600 samples/s @ 50Hz,	Current input impedance	0.0144
	1900 samples/s @ 60Hz	5(6)A	< 0.3VA
Display refresh time	1 second	Voltage input impedance Self-power supply	Power consumption: <2VA.
Display	2 lines	Frequency	45 to 65 Hz.
	1 <sup>st</sup> line: 7-DGT,		Two push buttons for vari-
	2 <sup>nd</sup> line: 3-DGT or 1 <sup>st</sup> line: 3-DGT + 3-DGT,	Key-pad	able selection and pro-
	2 <sup>nd</sup> line: 3-DGT + 3-DGT,		gramming of the instru-
Туре	LCD, h 7mm.		ment working parameters.
Instantaneous variables read-out	3-DGT.		<u> </u>



## **Output specifications**

Pulse output Number of outputs Type	1 Programmable from 0.01 to 9.99 kWh per pulses. Out- put connectable to the	Protocol Data (bidirectional) Dynamic (reading only)	MODBUS/JBUS (RTU)  System and phase variables: see table "List of variables"
Pulse duration	energy meters (kWh) ≥100ms < 120ms (ON), ≥120ms (OFF), according to EN62052-31.	Static (reading and writing)  Data format	All the configuration parameters.  1 start bit, 8 data bit, no parity, 1 stop bit.
Output	Static: opto-mosfet.	Baud-rate	9600 bits/s.
Load	V <sub>ON</sub> 2.5 VAC/DC max. 70 mA, V <sub>OFF</sub> 260 VAC/DC max.	Driver input capability	1/5 unit load. Maximum 160 transceiver on the
Insulation	By means of optocouplers, 4000 VRMS output to measuring inputs.	Insulation	same bus. By means of optocouplers, 4000 VRMS output to mea-
RS485			suring input.
Туре	Multidrop, bidirectional (static and dynamic variables)		
Connections	2-wire. Max. distance 1000m, termination directly on the instrument.		
Addresses	247, selectable by means of the front keypad		

## **Software functions**

Password  1st level  2nd level  Programming lock	Numeric code of max. 3 digits; 2 protection levels of the programming data: Password "0", no protection; Password from 1 to 999, all data are protected By means of potentiometer (back-side of the display module) it is possible to lock the access to all the configuration parameters.	Transformer ratio VT (PT) CT	1.0 to 99.9 / 100 to 999 / 1.00k to 6.00k 1.0 to 99.9 / 100 to 999 / 1.00k to 9.99k / 10.0k to 60.0k. The maximum power being measured cannot exceed 210 MW calculated as maximum input voltage and current, (see the "Accuracy" paragraph). The maximum VT by CT
System selection			ratio is 48.600. For MID
System 3-Ph.n unbalanced load	3-phase (4-wire) 3-phase (3-wire)		complaint applications the maximum power being
System 3-Ph.1 balanced load	• 3-phase (3-wire) one cur-		measured is 25 MW.
	rent and 3-phase to phase voltage measurements.  Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage.  • 3-phase (4-wire) one cur-	<b>Displaying</b>	Up to 3 variables per page. See « Display pages », 3 different set of variables available (see « Display pages ») according to the metering function being selected.
	rent and 3-phase to neutral voltage measurements.  Note: the phase to phase	Reset	By means of the front key- pad: total energies (kWh, kvarh).
System 2-Ph System 1-Ph	voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage.  • 3-phase (2-wire) one current and 1-phase (L1) to neutral voltage measurement.  2-phase (3-wire)  1-phase (2-wire)	Easy connection function	Wrong phase detection and displaying. For all the display selections, both energy and power mea- surements are independent from the current direction. The displayed energy is always "imported".



## **General specifications**

Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C) according to EN62053-21 and EN62053-23.	Radio frequency suppression  Standard compliance Safety	measuring inputs circuit: 6kV; According to CISPR 22
Storage temperature			IEC60664, IEC61010-1 EN60664, EN61010-1 EN62052-11 EN62053-21, EN62053-23, MID "annex MI-003" DIN43864, IEC62053-31 CE
Installation category	Cat. III (IEC60664,	Approvals  Connections	~-
Insulation (for 1 minute)	EN60664).  4000 VRMS between measuring inputs and digital output.	Cable cross-section area	Screw-type 2.4 x 3.5 mm Min./Max. screws tighten- ing torque: 0.4 Nm / 0.8 Nm
Dielectric strength	4000 VRMS for 1 minute.	Housing	
Noise rejection CMRR	100 dB, 48 to 62 Hz.	Dimensions (WxHxD)	72 x 72 x 65 mm
EMC Electrostatic discharges Immunity to irradiated Electromagnetic fields  Burst Immunity to conducted disturbances Surge	According to EN62052-11 15kV air discharge; Test with current: 10V/m from 80 to 2000MHz; Test without any current: 30V/m from 80 to 2000MHz; On current and voltage measuring inputs circuit: 4kV 10V/m from 150KHz to 80MHz On current and voltage	Mounting Protection degree Front Screw terminals Weight	Noryl PA66, self-extinguishing: UL 94 V-0 Panel and DIN-rail  IP50 IP20  Approx. 400 g (packing included)

## **Power supply specifications**

Self power supply	18 to 260VAC (48-62Hz). Across input "VL1" and "N"	Power consumption	≤2VA/1W

#### Insulation between inputs and outputs


	Measuring Inputs	Opto-Mosfet output	Communication port	Self power supply
Measuring Inputs	-	4kV	4kV	0kV
Opto-Mosfet output	4kV	-	-	4kV
Communication port	4kV	-	-	4kV
Self power supply	0kV	4kV	4kV	-

NOTE: all the models have, mandatorily, to be connected to external current transformers.




#### Accuracy (According to EN50470-3 and EN62053-23)

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



#### MID "Annex MI-003" compliance

**Accuracy** 

 $0.9 \text{ Un} \le U \le 1.1 \text{ Un};$  $0.98 \text{ fn} \le f \le 1.02 \text{ fn};$ fn: 50 or 60Hz; cosφ: 0.5 inductive to 0.8 capacitive. Class B I st: 0.01A; I min: 0.05A; I tr: 0.25A;

	I n: 5A I max: 6A.
Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)
EMC compliance	E2

#### **Used calculation formulas**

#### Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n} \cdot \sum_{i}^{n} (V_{1N})_{i}^{2}}$$
Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_{i=1}^{n} (V_{1N})_i \cdot (A_1)_i$$

Instantaneous power factor

$$\cos \varphi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_1 = \sqrt{\frac{1}{n} \cdot \sum_{1}^{n} (A_1)_i^2}$$

Instantaneous apparent power

$$VA_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power  $var_1 = \sqrt{(VA_1)^2 - (W_1)^2}$ 

#### System variables

Equivalent three-phase voltage

$$V_{\Sigma} = \frac{V_1 + V_2 + V_3}{3} \cdot \sqrt{3}$$

Voltage asymmetry

Three-phase active power

Three-phase apparent power

 $W_{\Sigma} = W_1 + W_2 + W_3$ 

 $VA_{\Sigma} = \sqrt{W_{\Sigma}^2 + \text{var}_{\Sigma}^2}$ 

Three-phase power factor

$$\cos \varphi_{\Sigma} = \frac{W_{\Sigma}}{VA_{\Sigma}}$$

(TPF)

#### **Energy metering**

$$k \operatorname{var} hi = \int_{t_1}^{t_2} Qi(t) dt \cong \Delta t \sum_{t_1}^{n_2} Qnj$$

$$kWhi = \int_{t1}^{t2} Pi(t)dt \cong \Delta t \sum_{n1}^{n2} Pnj$$

#### Where:

i= considered phase (L1, L2 or L3) P= active power; Q= reactive power; t<sub>1</sub>, t<sub>2</sub> =starting and ending time points of consumption recording; n= time unit;∆t= time interval between two successive power consumptions;  $n_1$ ,  $n_2$  = starting and ending discrete time points of consumption recording



# List of the variables that can be connected to:

- RS485 communication port
- Pulse outputs (only "energies")

No	Variable	1-ph. sys.	2-ph. sys.	3-ph. 4-wire balanced system	3-ph. 3-wir balanced system	3-ph. 4-wire unbalanced system	3-ph. 3-wir unbalanced system	Notes
1	kWh	Х	Х	X	Х	Х	Х	Total
2	kvarh	Х	Х	Х	Х	х	Х	Total
3	V L-N sys (1)	0	Х	Х	Х	Х	Х	sys=system (∑)
4	V L1	Х	Х	Х	Х	Х	Х	
5	V L2	0	Х	Х	Х	Х	Х	
6	V L3	0	0	Х	Х	х	Х	
7	V L-L sys (1)	0	Х	Х	Х	Х	Х	sys=system (∑)
8	V L1-2	0	Х	Х	Х	Х	Х	
9	V L2-3	0	0	Х	Х	х	Х	
10	V L3-1	0	0	Х	Х	х	Х	
11	A L1	Х	Х	Х	Х	х	Х	
12	A L2	0	Х	Х	Х	х	Х	
13	A L3	0	0	Х	Х	Х	Х	
14	VA sys (1)	Х	Х	Х	Х	Х	Х	sys=system (∑)
15	VA L1 (1)	Х	Х	Х	Х	Х	Х	
16	VA L2 (1)	0	Х	Х	Х	х	Х	
17	VA L3 (1)	0	0	Х	Х	х	Х	
18	var sys	Х	Х	Х	Х	х	Х	sys=system (∑)
19	var L1 (1)	Х	Х	Х	Х	Х	Х	
20	var L2 (1)	0	Х	Х	Х	х	Х	
21	var L3 (1)	0	0	Х	Х	х	Х	
22	W sys	Х	Х	Х	Х	Х	Х	sys=system (∑)
23	W L1 (1)	Х	Х	Х	Х	Х	Х	
24	W L2 (1)	0	Х	Х	Х	х	Х	
25	W L3 (1)	0	0	Х	Х	Х	Х	
26	PF sys	Х	Х	Х	Х	Х	Х	sys=system (∑)
27	PF L1	Х	Х	Х	Х	Х	Х	
28	PF L2	0	Х	Х	Х	Х	Х	
29	PF L3	0	0	Х	Х	Х	Х	
30	Hz	Х	Х	Х	Х	Х	Х	
31	Phase sequence	0	0	Х	Х	Х	Х	

- (x) = available
- (o) = not available (zero indication on the display)
- (1) = Variable available only through the serial communication port RS485

## **Display pages**

No	1st variable	2nd variable	3rd variable	Note		le Note Ar		Application	
NO	(1st half-line)	(2 <sup>nd</sup> half-line)	(2nd line)	Note	Α	В	С		
	Phase sequence			The phase sequence tringle appears in any page only if there is a phase reverse	х	х	x		
1	Total	kWh	W sys		Х	Х	Х		
2	Total	kvarh	kvar sys			Х	х		
3		PF sys	Hz	Indication of C, -C, L, -L depending on the quadrant	х	Х	х		
4	PF L1	PF L2	PF L3	Indication of C, -C, L, -L depending on the quadrant			х		
5	A L1	A L2	A L3				х		
6	V L1-2	V L2-3	V L3-1				Х		
7	V L1	V L2	V L3				х		




## Additional available information on the display

Туре	1st line	2nd line	note
Meter information 1	Y. 2007	r.A0	Year of production and firmware release
Meter information 2	value	LEd (kWh)	KWh per pulse of the LED
Meter information 3	SYS [3P.n]	value	System type and connection type
Meter information 4	Ct rAt.	value	Current transformer ratio
Meter information 5	Ut rAt.	value	Voltage transformer ratio
Meter information 6	PuLSE (kWh)	value	Pulse output: kWh per pulse
Meter information 7	Add	value	Serial communication address


## List of selectable applications

	Description	Notes
Α	Active energy meter	Active energy measurement with some minor parameters
В	Active and reactive energy meter	Active and reactive energy measurement with some minor parameters
С	Full set of variables	Full set of available variables can be displayed

## One instrument with double mounting capability



By means of the patented detachable display it is possible to configure the same instrument either as a panel mounting meter or...




... a DIN-rail mounting meter.




#### **Wiring diagrams**


# 


#### (6A) Self power supply, system type selection: 3P.n







#### (6A) System type selection: 3P.n









#### (6A) Self power supply, system type selection: 3P.1












#### **Wiring diagrams**

#### (6A) System type selection: 2P







#### (6A) System type selection: 1P




## Static output wiring diagram

#### (6A) System type selection: 1P






## RS485 port wiring diagram



RS485 NOTE: additional devices provided with RS485 are connected as per the picture above. The termination of the serial output is carried out only on the last instrument of the network, by means of a jumper between (B+) and (T).




#### Front panel description



- 1. Keypad
  - To program the configuration parameters and scroll the variables on the display.
- Pulse output LED
   Red LED blinking proportional to the energy being
- Display LCD-type with alphanumeric indications to display all the measured variables.
- 4. Connections Screw terminal blocks for instrument wiring.
- 5. Green LED
  Lit when power supply is available

#### **Dimensions (DIN configuration)**



# Dimensions and panel cut out (72x72 panel mounting configuration)

