

Energy Management Energy Analyzer Type EM24 DIN



- Protection degree (front): IP50
- RS485 serial output (on request) (MODBUS-RTU), iFIX SCADA compatibility
- Dupline communication capability (DP option)
- Application adaptable display and programming procedure (Easyprog function)
- Easy connections management
- Certified according to MID Directive, Annex "B" "Type examination" relevant to active electrical energy meters (see Annex MI-003).

- Class 1 (kWh) according to EN62053-21
- Class B (kWh) according to EN50470-3
- Class 2 (kvarh) according to EN62053-23
- Accuracy ± 0.5 RDG (current/voltage)
- Energy analyzer
- Instantaneous variables readout: 4 DGT
- Energies/gas/water readout: 7+1 DGT
- System variables: VLL, VLN, Admd max, VA, VAdmd, VAdmd max, W, Wdmd, Wdmd max, var, PF, Hz, Phase-sequence.
- Single phase variables: VLL, VLN, A, VA, W, var, PF
- Energy measurements: total and partial kWh and kvarh or based on 4 different tariffs; single phase measurements
- Gas, cold water, hot water, kWh remote heating measurements
- Hour counter (6+2 DGT)
- TRMS measurements of distorted sine waves (voltages/currents)
- Self power supply (AV0-AV2-AV9 inputs)
- Auxiliary power supply (AV5-AV6 inputs)
- 3 digital inputs for tariff selection, DMD synch or gas/water (hot-cold) and remote heating metering (on request)
- 2 digital outputs for pulses or for alarms or as a mix of them (on request)
- Dimensions: 4-DIN modules

Product Description

Three-phase energy analyzer with built-in configuration joystick and LCD data displaying; particularly indicated for active and reactive energy metering and for cost allocation. Housing for DIN-rail mounting with IP50 (front) protection degree. Direct connection up to 65A and by means of external current and potential trans-

formers. Moreover the meter can be provided with digital outputs that can be either for pulse proportional to the active and reactive energy being measured or for alarm outputs. In alternative the RS485 communication port and 3 digital inputs or Dupline port and 3 digital inputs are available as an option.

How to order

EM24 DIN AV5 3 X O2 X

Model	_____
Range code	_____
System	_____
Power supply	_____
Inputs/Outputs	_____
Option	_____

Type Selection

Range codes	System	Inputs/Outputs	Power supply
AV5: 400V _{LL} AC - 1/5 (10)A (CT connection) (*) V _{LN} : 160 V to 480V _{LN} V _{LL} : 277 V to 830V _{LL}	1: 1-phase, 2-wire; 3-phase, 3-wire, 3-phase, 4-wire balanced load (**) 3: balanced and unbalanced load: 3-phase, 4-wire; 3-phase, 3-wire; 2-phase, 3-wire; 1-phase, 2-wire (*)	XX: none (*) O2: dual open collector type (dual pulse or one pulse + one alarm or dual alarm) (*) R2: dual relay type (functions as per "O2") (**)(°) XS: RS485 port (**) IS: 3 digital inputs for tariff selection or Gas / water / remote heating metering plus RS485 port (*)	X: Self power supply (See "Power supply specifications") (*) L: 18 to 60VAC/DC (48 to 62Hz) (**) D: 115/230 VAC (48 to 62Hz) (*) Note: "L" and "D" power supplies only for AV5 and AV6 inputs; "X" power supply only for AV0, AV2 and AV9 inputs.
AV6: 208V _{LL} AC - 1/5(10)A (VT/PT and CT connections) (*) V _{LN} : 40V to 144V _{LN} V _{LL} : 70V to 250V _{LL}			
AV0: 208V _{LL} AC -10(65)A (direct connection) (**) V _{LN} : 96V to 144V _{LN} V _{LL} : 166V to 250V _{LL}			
AV2: 400V _{LL} AC 10(65)A (direct connection) (**) V _{LN} : 113V to 265V _{LN} V _{LL} : 196V to 460V _{LL}	P: Certified according to MID Directive, Annex "B" "Type examination" relevant to active electrical energy meters (see Annex MI-003) (*) X: none	DP: Dupline port plus 3 digital inputs for Gas / water / remote heating metering (°)	
AV9: 400V _{LL} AC - 10(65)A (direct connection) (*) V _{LN} : 184V to 276V _{LN} V _{LL} : 318V to 480V _{LL}			

(*) as standard. (**) on request.

(°) not available if the range code is "AV2". (°°) available if the range code is either "AV2" or "AV5".

Input specifications

Rated inputs		
Current type	System type: 3-phase Galvanic insulation by means of built-in CT's (AV5 and AV6 models). By direct connection (AV0, AV2 and AV9)	Type Instantaneous variables read-out Energies
Current range (by CT) Current range (direct)	AV5 and AV6: 1/5(10)A AV0: 10(65)A; AV2: 10(65)A; AV9: 10(65)A	Overload status EEEE indication when the value being measured is exceeding the "Continuous inputs overload" (maximum measurement capacity)
Voltage Voltage	AV5: 400 VLL AV0: 120VLN/208 VLL AV2: 230/400 VLL AV9: 400 VLL	Max. and Min. indication Max. instantaneous variables: 9999; energies: 9 999 999.9 or 99 999999. Min. instantaneous variables: 0.000; energies 0.0
Voltage by VT/PT	AV6: 120VLN/208 VLL	
Accuracy (Display + RS485) (@25°C ±5°C, R.H. ≤60%, 48 to 62Hz)	lb: see below, Un: see below	
AV5 model	In: 5A, Imax: 10A; Un: 160 to 480VLN (277 to 830VLL)	LEDs Red LED (Energy consumption) 0.001 kWh/kvarh by pulse if CT ratio by VT ratio is ≤7; 0.01 kWh/kvarh by pulse if CT ratio x VT ratio is > 7.1 ≤70.0; 0.1 kWh/kvarh pulse if CT ratio x VT ratio is > 70.1 ≤700.0; 1 kWh/kvarh by pulse if CT ratio x VT ratio is > 700.1; 0.001kWh/kvarh by pulse 16Hz, according to EN50470-3
AV6 model	In: 5A, Imax: 10A; Un: 40 to 144VLN (70 to 250VLL)	
AV0 model	Ib: 10A, Imax: 65A; Un: 96 to 144VLN (166 to 250VLL)	
AV2 model	Ib: 10A, Imax: 65A, Un: 113 to 265VLN (196 to 460VLL)	
AV9 model	Ib: 10A, Imax: 65A; Un: 184 to 276VLN (318 to 480VLL)	
Current AV5, AV6 models	From 0.002In to 0.2In: ±(0.5% RDG +3DGT) From 0.2In to Imax: ±(0.5% RDG +1DGT).	
AV0, AV2, AV9 models	From 0.004lb to 0.2lb: ±(0.5% RDG +3DGT) From 0.2lb to Imax: ±(0.5% RDG +1DGT).	
Phase-neutral voltage	In the range Un: ±(0.5% RDG +1DGT)	Measurements See "List of the variables that can be connected to:" TRMS measurements of distorted wave forms.
Phase-phase voltage	In the range Un: ±(1% RDG +1DGT)	Method Coupling type
Frequency	±0.1Hz (45 to 65Hz)	Direct for AV0, AV2 and AV9 models. By means of external CT's for AV5 and AV6
Active and Apparent power	±(1%RDG +2DGT)	
Power Factor	±[0.001+1%(1.000 - "PF RDG")]	
Reactive power	±(2%RDG +2DGT)	Crest factor Ib 10A ≤4 (91A max. peak) In 5A ≤3 (15A max. peak)
Active energy	Class 1 according to EN62053-21 and MID Annex MI-003 Class B according to EN50470-3	
Reactive energy	Class 2 according to EN62053-23	
AV5, AV6 models	Ib: 5A, Imax: 10A; 0.1 lb: 0.5A, Start up current: 10mA	Current Overloads Continuous For 500ms For 10ms
AV0, AV2, AV9 models	Ib: 10A, Imax: 65A; 0.1 lb: 1.0A Start up current: 40mA	1/5(10) A: 10A, @ 50Hz 10(65) A: 65A, @ 50Hz 1/5(10) A: 200A, @ 50Hz 10(65) A: 1920A max, @ 50Hz
Energy additional errors		Voltage Overloads Continuous For 500ms
Influence quantities	According to EN62053-21, EN50470-3, EN62053-23	1.2 Un 2 Un
Temperature drift	≤200ppm/°C	Input impedance 208VL-L (AV6) 208VL-L (AV0)
Sampling rate	1600 samples/s @ 50Hz 1900 samples/s @ 60Hz	230/400VL-L (AV2) 400VL-L (AV5) 400VL-L (AV9)
Display refresh time	750 ms	1/5(10)A (AV5-AV6) 10(65)A (AV0-AV2-AV9)
Display	3 lines (1 x 8 DGT; 2 x 4 DGT)	Frequency 45 to 65 Hz
		Joystick For variable selection and programming of the instrument working parameters

Output specifications

Digital outputs		Note	The meters equipped with the relay outputs ("AV0" and "AV9" models with "R2" option) work even if VL3 is missing (VL1, VL2 and neutral have to be available)(see table "working mode notes")
Pulse type			
Number of outputs	Up to 2, independent. Programmable from 0.001 to 10.00kWh/kvarh by pulse.		
Type	Outputs connectable to the energy meters (kWh/kvarh)		
Pulse duration	$\geq 100\text{ms} < 120\text{msec (ON)}$, $\geq 120\text{ms (OFF)}$, according to EN62053-31		
Alarm type		RS485	
Number of outputs	Up to 2, independent	Type	Multidrop, bidirectional (static and dynamic variables)
Alarm modes	Up alarm, down alarm (see the table "List of the variables that can be connected to")	Connections	2-wire
Set-point adjustment	From 0 to 100% of the display scale	Addresses	Max. distance 1000m
Hysteresis	From 0 to full scale	Protocol	247, selectable by means of the front joystick
On-time delay	0 to 255s	Data (bidirectional)	MODBUS/JBUS (RTU)
Output status	Selectable; normally de-energized or normally energized	Dynamic (reading only)	
Min. response time	$\leq 700\text{ms}$, filter excluded, set-point on-time delay: "0 s"	Static (reading and writing)	System and phase variables: see table "List of variables..."
Note	The 2 digital outputs can also work as a dual pulse output, dual alarm output, one pulse output and one alarm output.	Data format	All the configuration parameters.
		Baud-rate	1 start bit, 8 data bit, no parity, 1 stop bit
		Driver input impedance	4800, 9600 bit/s
		Insulation	1/5 unit load
			Maximum 160 transceivers on the same bus.
			By means of optocouplers, 4000 VRMS output to measuring input,
			4000 VRMS output to power supply input.
Static output			
Purpose	For pulse output or alarm output	Note:	
Signal	V_{ON} 1.2 VDC/ max. 100 mA V_{OFF} 30 VDC max.		The meters equipped with the communication port ("AV0" and "AV9" models with "XS" and "IS" options) work even if VL3 is missing (VL1, VL2 and neutral have to be available)(see table "working mode notes")
Insulation	By means of optocouplers, 4000 VRMS output to measuring inputs, 4000 VRMS output to power supply input.		
Relay output			
Purpose	For alarm output or pulse output		
Type	Relay, SPST type AC 1-5A @ 250VAC DC 12-5A @ 24VDC AC 15-1.5A @ 250VAC DC 13-1.5A @ 24VDC		
Insulation	4000 VRMS output to measuring input 4000 VRMS output to power supply input.		

Dupline specifications

Counters	Multiplexer for counter values 6 per instrument 128 per network 0... 99 999 999 B to F B2 to B8 B1 C1 to F8 Enable/disable function for all the counters kWh tot, -kWh tot, kvarh tot, -kvarh tot, kWh t1, kWh t2, kWh L1, kWh L2, kWh L3, counter dig. in. 1, counter dig. in. 2, counter dig. in. 3, hour counter.	Available variables Synchro/Tariff input Used Dupline functions Used channels Working mode	variables) M1 to N8 (4 th group of 16 variables) O1 to P8 (5 th group of 16 variables) All, except for the "max" variables
Analogue variables	Multiplexer for analogue values 8 per instrument 80 per network	Used Dupline function Used channels	Monostable (push-button) Realtime A5 Selectable: <ul style="list-style-type: none">• none• Wdmd synchronization• total and partial energy meter (kWh, kvarh) managed by time periods (t1-t2).
Dupline data format	3 1/2 DGT BCD Selectable from 1.999 to 1999M depending on the number of variables A1 to A4 G1 to H8 (1 st group of 16 variables) I1 to J8 (2 nd group of 16 variables) K1 to L8 (3 rd group of 16	Number of alarms Alarm modes Set-point adjustment Hysteresis On-time delay Output status Available variables	Monostable (push-button) Selectable (A1 to P8). No control that the selected channels are not used for counters or analog variables. 2 per instrument Up alarm, down alarm (see the table "List of the variables that can be connected to") From 0 to 100% of the display scale From 0 to full scale 0 to 255s Normally energised All, except for the "max" variables
Number of inputs Input frequency Prescaler adjustment	3 20Hz max, duty cycle 50% From 0.1 to 999.9 m ³ or kWh per pulse 5VDC +/- 5% 10mA max 680Ω	Working modes (DP version only)	managed by time periods (t1-t2), W dmd synchronisation (the synchronisation is made independently from the tariff selection) and GAS (m ³) or WATER (hot-cold m ³) or remote heating (kWh) meters;
Contact measuring voltage Contact measuring current Input impedance Contact resistance	≤100Ω, closed contact ≥500kΩ, open contact	Note	<ul style="list-style-type: none">• total energy (kWh, kvarh) and GAS, WATER (hot-cold m³) and remote heating meters (3 choices only).
Working modes (DP version excluded)	Selectable: <ul style="list-style-type: none">• total and partial energy meters (kWh and kvarh) without digital inputs;• total and partial energy meters (kWh and kvarh) managed by time periods (t1-t2-t3-t4), W dmd synchronisation (the synchronisation is made every time the tariff changes) and GAS (m³) or WATER (hot-cold m³) or remote heating (kWh) meters;• total and partial energy meters (kWh and kvarh)	Insulation	<ul style="list-style-type: none">• GAS (m³) or WATER (hot-cold m³) or remote heating (kWh) meters

Digital input specifications

Number of inputs	3	managed by time periods (t1-t2), W dmd synchronisation (the synchronisation is made independently from the tariff selection) and GAS (m ³) or WATER (hot-cold m ³) or remote heating (kWh) meters;
Input frequency	20Hz max, duty cycle 50%	
Prescaler adjustment	From 0.1 to 999.9 m ³ or kWh per pulse	
Contact measuring voltage	5VDC +/- 5%	
Contact measuring current	10mA max	
Input impedance	680Ω	
Contact resistance	≤100Ω, closed contact ≥500kΩ, open contact	
Working modes (DP version excluded)	Selectable: <ul style="list-style-type: none">• total and partial energy meters (kWh and kvarh) without digital inputs;• total and partial energy meters (kWh and kvarh) managed by time periods (t1-t2-t3-t4), W dmd synchronisation (the synchronisation is made every time the tariff changes) and GAS (m³) or WATER (hot-cold m³) or remote heating (kWh) meters;• total and partial energy meters (kWh and kvarh)	
	Working modes (DP version only)	<ul style="list-style-type: none">• GAS (m³) or WATER (hot-cold m³) or remote heating (kWh) meters
	Note	The energy metering is only made by means of the analogue inputs.
	Insulation	By means of optocouplers, 4000 VRMS digital inputs to measuring inputs, 4000 VRMS digital inputs to power supply input.

Software functions

Password	Numeric code of max. 4 digits; 2 protection levels of the programming data: Password "0", no protection Password from 1 to 9999, all data are protected	Operating range Filtering coefficient Filter action	0 to 100% of the input display scale 1 to 32 Measurements, serial output (fundamental variables: V, A, W and their derived ones).
System selection	System 3-Pn unbalanced load System 3-P unbalanced load System 3-P1 (only AV5 and AV6) balanced load System 2-P System 1-P	3-phase (4-wire) 3-phase (3-wire) 3-phase (3-wire) one current and 3-phase to phase voltage measurements 3-phase (4-wire) one current and 1-phase (L1) to neutral voltage measurement 2-phase (3-wire) 1-phase (2-wire)	Up to 3 variables per page (see « Display pages ») 8 different set of variables available (see « Display pages ») according to the application being selected
Transformer ratio	VT (PT) CT	1.0 to 999.9 / 1000 to 6000 (only AV5 and AV6) 1.0 to 999.9 / 1000 to 9999 / 10.00k to 60.00k (only AV5 and AV6). The maximum power being measured cannot exceed 210 MW (calculated as maximum input voltage and current, see the "Accuracy" paragraph before). The maximum VT by CT ratio is 48600. For MID compliant applications the maximum power being measured is 25MW.	By means of the front joystick: - dmd and dmd max; - total energies (kWh and kvarh) and gas/water; - partial energies and tariffs: kWh, kvarh
Filter			Easy connection function AV0, AV2 and AV9 models AV5-AV6-AV0-AV2-AV9 models
			Automatic phase sequence detection with current and voltage synchronisation. For all the display selections, both energy and power measurements are independent from the current direction. The displayed energy is always "imported" with the only exception of "F" and "H" types (see "display pages" table). For those latter selections the energies can be either "imported" or "exported" depending on the current direction.

General specifications

Operating temperature	-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C) according to EN62053-21, EN50470-1 and EN62053-23	Dielectric strength 4000 VRMS for 1 minute
Storage temperature	-30°C to +70°C (-22°F to 158°F) (R.H. < 90% non-condensing @ 40°C) according to EN62053-21, EN50470-1 and EN62053-23	Noise rejection CMRR 100 dB, 48 to 62 Hz
Installation category	Cat. III (IEC60664, EN60664)	EMC Electrostatic discharges Immunity to irradiated
Insulation (for 1 minute)	4000 VRMS between measuring inputs and power supply 4000 VRMS between power supply and RS485/digital output	According to EN62052-11 15kV air discharge Test with current: 10V/m from 80 to 2000MHz Test without any current: 30V/m from 80 to 2000MHz On current and voltage measuring inputs circuit: 4kV
		Immunity to conducted disturbances 10V/m from 150KHz to 80MHz
		Burst On current and voltage measuring inputs circuit: 4kV; on "L" auxiliary power supply input: 1kV
		Surge Radio frequency suppression According to CISPR 22

General specifications (cont.)

Standard compliance		
Safety	IEC60664, IEC61010-1 EN60664, EN61010-1 (EN62052-11) EN50470-1. EN62053-21, EN62053-23, EN50470-3.	Min./Max. screws tightening torque: 0.4 Nm / 0.8 Nm
Metrology	Cable cross-section area AV5-AV6 models	Max. 1.5 mm ² Min./Max. screws tightening torque: 0.4 Nm / 0.8 Nm
Pulse output		
Approvals	MID "annex MI-003" DIN43864, IEC62053-31 CE, MID according to "annex B" (EC type certificate)	71 x 90 x 64.5 mm Nylon PA66, self-extinguishing: UL 94 V-0 DIN-rail
Connections		
Cable cross-section area AV0-AV2-AV9 models	Screw-type Max. 16 mm ² ; Min. 2.5 mm ² (measuring inputs); Min./Max. screws tightening torque: 1.7 Nm / 3 Nm Other inputs: 1.5 mm ²	Protection degree Front IP50 Screw terminals IP20 Weight Approx. 400 g (packing included)

Power supply specifications


Self supplied version	AV9-AV0 models “XX” and “O2” options only: -20% +15%, 48-62Hz. “R2”, “XS” and “IS” options only: -15% +10%, 48-62Hz. AV2 model: “XX”, “O2”, “IS” and “DP” options: -15% +15%, 48-62Hz. In case of 3-phase system, 4-wire connection: 113 to 265V. In case of 3-phase system, 3-wire connection: 196 to 460V. The instruments provided with “IS” and “R2” options work only if all the voltage inputs are connected (3-phase and neutral) if a 1-phase connection has to	be performed the L1 and L2 voltage inputs have to be short circuited. The instrument provided with “O2” option, working in a 3-phase system with neutral may work also if one or two phases are missing.						
Note								
	Auxiliary power supply	AV5-AV6 modules: L: 18 to 60VAC/DC; D: 115VAC/230VAC (48 to 62Hz)						
	Power consumption	<table border="0"> <tr> <td>AV9-AV2-AV0 models</td> <td>≤ 20VA/1W</td> </tr> <tr> <td>AV9-AV2-AV0 models (IS and DP option only)</td> <td>≤ 12VA/2W</td> </tr> <tr> <td>AV5-AV6 models</td> <td>≤ 2VA/2W</td> </tr> </table>	AV9-AV2-AV0 models	≤ 20VA/1W	AV9-AV2-AV0 models (IS and DP option only)	≤ 12VA/2W	AV5-AV6 models	≤ 2VA/2W
AV9-AV2-AV0 models	≤ 20VA/1W							
AV9-AV2-AV0 models (IS and DP option only)	≤ 12VA/2W							
AV5-AV6 models	≤ 2VA/2W							

Working mode notes (only "Self power supply" version)


Output	Model	Note
Open collector output	"AV0" and "AV9" models with "O2" option	The meter works even if up to two voltages "phase to neutral" are missing or if one voltage "phase to phase" is missing.
Relay output	"AV0" and "AV9" models with "R2" option	The neutral wire has always to be available. The meter works even if "Phase 3" is missing but, mandatorily, both "phase 1" and "Phase 2" have to be available.
RS485 port	"AV0" and "AV9" models with "XS" and "IS" options	
Dupline port	"AV2" model with "DP" option	
Relay output	"AV2" model with "R2" option	
RS485 port	"AV2" model with "XS", "IS" options	

Accuracy (According to EN50470-3 and EN62053-23)

kWh, accuracy (RDG) depending on the current



kvarh, accuracy (RDG) depending on the current



MID “Annex MI-003” compliance

Accuracy

0.9 Un ≤ U ≤ 1.1 Un; 0.98 fn ≤ f ≤ 1.02 fn; fn: 50 or 60Hz; cosφ: 0.5 inductive to 0.8 capacitive. Class B I st: 0.04A; I min: 0.5A; I tr: 1A; I ref: 10A; I max: 65A.

AV0-AV2-AV9 models

AV5-AV6 models

Class B
I st: 0.01A;
I min: 0.05A;
I tr: 0.25A;
I ref: 5A;
I max: 10A.

Operating temperature

-25°C to +55°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)

EMC compliance

E2

Used calculation formulas

Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n} \cdot \sum_1^n (V_{1N})_i^2}$$

Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_1^n (V_{1N})_i \cdot (A_1)_i$$

Instantaneous power factor

$$\cos\phi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_1 = \sqrt{\frac{1}{n} \cdot \sum_1^n (A_1)_i^2}$$

Instantaneous apparent power

$$VA_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power

$$\text{var}_1 = \sqrt{(VA_1)^2 - (W_1)^2}$$

System variables

Equivalent three-phase voltage

$$V_\Sigma = \frac{V_1 + V_2 + V_3}{3} \cdot \sqrt{3}$$

Voltage asymmetry

$$\text{ASY}_{LL} = \frac{(V_{LL\max} - V_{LL\min})}{V_{LL} \Sigma}$$

$$\text{ASY}_{LN} = \frac{(V_{LN\max} - V_{LN\min})}{V_{LN} \Sigma}$$

Three-phase reactive power

$$\text{var}_\Sigma = (\text{var}_1 + \text{var}_2 + \text{var}_3)$$

Three-phase active power

$$W_\Sigma = W_1 + W_2 + W_3$$

Three-phase apparent power

$$VA_\Sigma = \sqrt{W_\Sigma^2 + \text{var}_\Sigma^2}$$

Three-phase power factor (TPF)

$$\cos\phi_\Sigma = \frac{W_\Sigma}{VA_\Sigma}$$

Energy metering

$$k\text{ var} h_i = \int_{t_1}^{t_2} Q_i(t) dt \cong \Delta t \sum_{n1}^{n2} Q_{nj}$$

$$k\text{ Whi} = \int_{t_1}^{t_2} P_i(t) dt \cong \Delta t \sum_{n1}^{n2} P_{nj}$$

Where:

i= considered phase (L1, L2 or L3)
P= active power; Q= reactive power;
t₁, t₂= starting and ending time points of consumption recording; n= time unit; Δt= time interval between two successive power consumptions; n₁, n₂= starting and ending discrete time points of consumption recording

List of the variables that can be connected to:

- RS485 communication port
- Alarm outputs (“max” variable”, “energies” and “hour counter” excluded)
- Pulse outputs (only “energies”)
- Dupline bus

No	Variable	1-phase system	2-phase system	3-ph. 4-wire balanced sys.	3-ph. 4-wire unbal. sys.	3 ph. 3-wire bal. sys.	3 ph. 3-wire unbal. sys.	Notes
1	V L-N sys	O	X	X	X	X	X	# sys=system
2	V L1	X	X	X	X	X	X	#
3	V L2	O	X	X	X	X	X	#
4	V L3	O	O	X	X	X	X	#
5	V L-L sys	O	X	X	X	X	X	sys=system
6	V L1-2	#	X	X	X	X	X	
7	V L2-3	#	O	X	X	X	X	
8	V L3-1	#	O	X	X	X	X	
9	A dmd max	O	X	X	X	X	X	Highest “dmd” current among the phases (1)(2)
10	A L1	X	X	X	X	X	X	
11	A L2	O	X	X	X	X	X	
12	A L3	O	O	X	X	X	X	
13	VA sys	X	X	X	X	X	X	sys=system
14	VA sys dmd	X	X	X	X	X	X	sys=system (1)
15	VA L1	X	X	X	X	X	#	
16	VA L2	O	X	X	X	X	#	
17	VA L3	O	O	X	X	X	#	
18	var sys	X	X	X	X	X	#	sys=system
19	var L1	X	X	X	X	X	#	
20	var L2	O	X	X	X	X	#	
21	var L3	O	O	X	X	X	#	
22	W sys	X	X	X	X	X	X	sys=system
23	W sys dmd	X	X	X	X	X	X	sys=system (1)
24	W L1	X	X	X	X	X	#	
25	W L2	O	X	X	X	X	#	
26	W L3	O	O	X	X	X	#	
27	PF sys	X	X	X	X	X	X	
28	PF L1	X	X	X	X	X	#	
29	PF L2	O	X	X	X	X	#	
30	PF L3	O	O	X	X	X	#	
31	Hz	X	X	X	X	X	X	
32	Phase seq.	O	X	X	X	X	X	
33	Hours	X	X	X	X	X	X	
34	kWh (+)	X	X	X	X	X	X	Total or by user
35	kvarh (+)	X	X	X	X	X	#	Total or by user
36	kWh (+)	X	X	X	X	X	X	Partial or by tariff
37	kvarh (+)	X	X	X	X	X	#	Partial or by tariff
38	kWh (-)	X	X	X	X	X	X	Total
39	kvarh (-)	X	X	X	X	X	#	Total
40	m ³ Gas	X	X	X	X	X	X	Total
41	m ³ Cold H ₂ O	X	X	X	X	X	X	Total
42	m ³ Hot H ₂ O	X	X	X	X	X	X	Total
43	kWh H ₂ O	X	X	X	X	X	X	Total

(X) = available

(O) = not available (zero indication on the display)

(#)= not available (the relevant page is not displayed)

(1)= max. value with data storage

(2)= not available with the “DP” option

Display pages

Sel. pos.	No	1st variable (1st line)	2nd variable (2nd line)	3rd variable (3rd line)	Note	Applications							
						A	B	C	D	E	F	G	H
	1	Phase seq.	VLN sys	Hz		7	7	7		7	7	7	7
	2	Phase seq.	VLL sys	Hz						x	x	x	
	3	Total kWh (+)	W sys dmd	W sys dmd max		x	x	x		x	x	x	x
	4	kWh (+)	A dmd max	(text) "PArt"	"PArt" = Partial kWh (+)					x	x	x	x
	5	Total kvarh (+)	VA sys dmd	VA sys dmd max			7	7			7	7	7
	6	kvarh (+)	VA sys	(text) "PArt"	"PArt" = Partial kvarh (+)					x	7	7	7
	7	Totalizer 1 (2)	W sys	(text) (3)	(1)			x		x	x	x	x
	8	Totalizer 2 (2)	W sys	(text) (3)	(1)			x		x	x	x	x
	9	Totalizer 3 (2)	W sys	(text) (3)	(1)			x		x	x	x	x
	10	kWh (+)	t1 tariff (4)	W sys dmd	(1) digital input enabled		x			x	x	x	x
	11	kWh (+)	t2 tariff (4)	W sys dmd	(1) digital input enabled		x			x	x	x	x
	12	kWh (+)	t3 tariff (4)	W sys dmd	(1) digital input enabled			5		5	5	5	5
	13	kWh (+)	t4 tariff (4)	W sys dmd	(1) digital input enabled			5		5	5	5	5
	14	kvarh (+)	t1 tariff (4)	W sys dmd	(1) digital input enabled			7		7	7	7	7
	15	kvarh (+)	t2 tariff (4)	W sys dmd	(1) digital input enabled			7		7	7	7	7
	16	kvarh (+)	t3 tariff (4)	W sys dmd	(1) digital input enabled			5,7		5,7	5,7	5,7	5,7
	17	kvarh (+)	t4 tariff (4)	W sys dmd	(1) digital input enabled			5,7		5,7	5,7	5,7	5,7
	18	kWh (+) X	W X	User X	(1) specific function enabled		x						
	19	kWh (+) Y	W Y	User Y	(1) specific function enabled		x						
	20	kWh (+) Z	W Z	User Z	(1) specific function enabled		x						
	21	Total kvarh (-)	VA sys dmd	VA sys dmd max							7		7
	22	Total kWh (-)	W sys dmd	W sys dmd max					x	x			x
	23	Hours	W sys	PF sys				x	x	x	x	x	x
	24	Hours	var sys	PF sys					7	7	7	7	7
	25	var L1	var L2	var L3							7		7
	26	VA L1	VA L2	VA L3								7	7
	27	PF L1	PF L2	PF L3								7	7
	28	W L1	W L2	W L3						7		7	7
	29	A L1	A L2	A L3					x	x	x	x	
	30	V L1-2	V L2-3	V L3-1								6	6
	31	V L1	V L2	V L3			7	7	7		7	7	
0	Selector position which can be linked to any of the variable combinations listed above (No. from 1 to 31)												
1	Selector position which can be linked to any of the variable combinations listed above (No. from 1 to 31)												
2	Selector position which can be linked to any of the variable combinations listed above (No. from 1 to 31)												
3	Selector position which can be linked to any of the variable combinations listed above (No. from 1 to 31) In this position the front LED blinks proportionally to the reactive energy (kvarh) being measured												

- (1) The page is available according to the enabled measurement.
- (2) m³ Gas, m³ Water, kWh remote heating.
- (3) Hot and Cold (water), GAS.
- (4) The active tariff is displayed with an "A" before the "t1-t2-t3-t4" symbols.
- (5) These pages are not available in case of Dupline system.
- (6) Pages not available in case of 1-phase system (1P selection).
- (7) Pages not available in case of 3-phase unbalanced system (3P selection).

Note: in case of alarm the whole display blinks. The blinking stops when either the selector or the joystick are used. The display starts to blink again after 60 seconds of the last command being used. There is a time-out of 60s that brings the scrolled page to the default one (selectable according to the table given above).

Additional available information on the display

Type	1st line	2nd line	3rd line
Meter information	Firmware revision	YEAr (text)	Year of production
Meter information	PuLSE (text)	LEd (text)	Numb. of kWh per pulse
Meter information	System (1-2-3-phase)	Connection (2-3-4-wire)	dmd (time)
Meter information	VT/PT ratio		
Meter information (AV5-6)	Ct rAtio (text)	1.0 ... 60.0k	
Meter information (AV5-6)	UT rAtio (text)	1.0 ... 6.0k	
In case of communication port	SEriAL (text)	Address number	RS485 status (RX-TX)
In case of Dupline port	Dupline (text) or EM24 (text)	OK ... err	

List of selectable applications

	Description	Notes
A	Basic domestic	Mainly energy metering
B	Shopping centres	Mainly energy metering
C	Advanced domestic	Mainly energy metering (total and based on tariff), gas and water metering
D	Multi domestic (also camping and marinas)	Mainly energy metering (3 by single phase)
E	Solar	Energy meter with some basic power analyzer functions
F	Industrial	Mainly energy metering
G	Advanced industrial	Energy metering and power analysis
H	Advanced industrial for power generation	Complete energy metering and power analysis

Insulation between inputs and outputs

	Measuring Inputs	Relay outputs	Open collector outputs	Comm. port and digital inputs	Dupline	Self power supply	Auxiliary power supply
Measuring Inputs	-	4kV	4kV	4kV	4kV	0kV	4kV
Relay outputs	4kV	-	-	-	-	4kV	4kV
Open collector outputs	4kV	-	-	-	-	4kV	4kV
Comm. port and digital inputs	4kV	-	-	-	-	4kV	4kV
Dupline	4kV	-	-	-	-	4kV	4kV
Self power supply	0kV	4kV	4kV	4kV	4kV	-	-
Aux. power supply	4kV	4kV	4kV	4kV	4kV	-	-

NOTE: all the models with auxiliary power supply have, mandatorily, to be connected to external current transformers because the isolation among the current inputs is just functional (100VAC).

Tamper proof accessory kit




The “tamper proof” kit is available with the “P” option (two screw protection covers).

The instrument can be sealed in three points:
 - Upper cover;
 - Lower cover;
 - Front selector (to lock the instrument programming);




Wiring diagrams




(65A) System type selection: 3P.n

3-ph, 4-wire, unbal./bal. load Fig.1



(65A) System type selection: 3P


3-ph, 3-wire, unbal./bal. load Fig. 2



The neutral connection is mandatory with "IS" or "R2" options.


(65A) System type selection: 2P

2-ph, 3-wire, unbal./bal. load Fig. 3




(65A) System type selection: 1P


1-ph, 2-wire, "O2" option Fig. 4



1-ph, 2-wire, "IS" and "R2" option Fig. 5




Note: the jumper between screw terminals "1" and "4" is not needed in case of "AV2" input range.




(10A) System type selection: 3P.n

3-ph, 4-wire, unbalanced load Fig. 6



3-CT connection

3-ph, 4-wire, unbalanced load Fig. 7




3-CT and 3-VT/PT connections


Wiring diagrams

(10A) System type selection: 3P.n


3-ph, 3-wire, unbalanced load **Fig. 8**



3-ph, 3-wire, unbalanced load **Fig. 9**




3-ph, 3-wire, unbalanced load **Fig. 10**




(10A) System type selection: 3P.1

3-ph, 3-wire, unbalanced load **Fig. 11**




3-ph, 3-wire, balanced load **Fig. 12**

1-CT connection



NOTE: a 2-wire connection for voltage measurement is available across (1) and (7).


3-ph, 3-wire, balanced load **Fig. 13**




1-CT and 2-VT/PT connections

(10A) System type selection: 2P

2-ph, 3-wire **Fig. 14**




2-ph, 3-wire **Fig. 15**






(10A) System type selection: 1P

1-ph, 2-wire **Fig. 16**






Wiring diagrams




(10A) System type selection: 1P



Power supply wiring diagrams (auxiliary power supply)







Open collector and relay outputs wiring diagrams




The load resistances (RC) must be designed so that the close contact current is lower than 100mA; the VDC voltage must be lower than or equal to 30VDC.

Digital inputs, RS485 and Dupline ports wiring diagrams



Front panel description



1. Joystick
To program the configuration parameters and scroll the variables on the display.
2. LED
Red LED blinking proportional to the energy being measured.
3. Display
LCD-type with alphanumeric indications to:
- display configuration parameters;
- display all the measured variables.
4. Selector
To select the desired display pages and to lock the programming.
5. Connections
Screw terminal blocks for instrument wiring.

Dimensions

